

ForeSite[®] EDGE

Variable Speed Drive
RPC Manual



Weatherford[®]

Contents

1. Purpose	3
2. Scope	3
3. Site Mobilization of VSD Equipment	3
4. Safety	3
5. VSD Installation Location	4
6. Electrical Installation	4
7. Rod Pump Controller Sensor Installation – Position Sensor	6
8. Rod Pump Controller Sensor Installation – Load Cell Sensor	10
9. Powering Up the VSD	20
10. Rotaflex Sensor Connection	21
11. Weatherford Rod Pump Controller Programming	22
12. Weatherford VSD Programming.....	33

	Description	Date
A	Initial Release	December 2020
B		July 2024

1. Purpose

- 1.1 The purpose of this Running Program (RP) is to install reciprocating rod lift (RRL) VSD at a non-conventional well site.

2. Scope

- 2.1 This running procedure includes instruction to safely install Weatherford ForeSite EDGE VSD on a conventional pumping unit. A mobile gripper unit, cranes, and suitable well control equipment (rated to 10k) will be used.

3. Site Mobilization of VSD Equipment


- 3.1 Pass Inspection

4. Safety

- 4.1 Statement of Compliance
- 4.2 Specific hazard identification (JHA) shall be conducted prior to commencing work to determine potential hazards which necessitate the implementation of controls including personal protective equipment (PPE).
- 4.3 Document the JHA using Toolbox Safety Meeting/Job Hazard Analysis Form, list the control measures required to reduce remaining hazards to As Low as Reasonably Practicable (ALARP), and identify the personnel responsible for ensuring the controls are in place.
- 4.4 Communicate the work process and JHA with all personnel during the Toolbox Talk
- 4.5 Field HAZID tools (if applicable) can be used as reference materials, pre-completed JHA's in the field are not permitted due to the dynamic environment.
- 4.6 Employees and sub-contractors, regardless of position or qualification, not only have the right but the obligation to stop any work if conditions are deemed to be unsafe or if a hazardous situation arises.
- 4.7 Management of Change (MOC) applies to this TWI/SOP; deviation is prohibited without authorization from an approved MOC.
- 4.8 Personal Protection Requirements (PPE)
- 4.9 Unless a risk assessment determines the need for additional specialized PPE, the following approved equipment is required; steel-toed footwear, safety glasses/eye wear, hardhat/helmet, gloves suitable for the task, coveralls and hearing protection.
- 4.10 Attain necessary permit to work


5. VSD Installation Location

- 5.1 This location should be leveled, secure, and within close proximity to the motor of the pumping unit.
- 5.2 VSD comes already installed on a skid base. Place the VSD front door or RPC HMI facing the pumping unit motor.




6. Electrical Installation

- 6.1 VSD cabinet main power inlet and outlet are located on the right side of the VSD.




- 6.2 Ensure the VSD circuit breaker is powered off.
- 6.3 Open the high voltage cabinet to access the terminals for VSD inlet and outlet (motor terminals)



- 6.4 Ensure proper energy isolation on the 3 phase power supply that feeds the VSD before wiring the VSD input and output terminals.
- 6.5 Drill holes and install proper sized glands for power cables inlet and motor cable outlet.
- 6.6 Remove the protective cover on the incoming terminals. Connect the 3 phase power inlet 480Vac/60Hz to the incoming terminals.
- 6.7 Connect the VSD ground bus bar to the earth ground bar.
- 6.8 Remove the protective cover on the outgoing terminals. Motor should be wired to the VSD output terminals in Delta connection. Connect the motor leads to the Outgoing terminals are marked. Motor ground wiring terminal is properly terminated on the VSD end.
- 6.9 Add the protective covers once incoming and outgoing terminal wiring is complete.


7. Rod Pump Controller Sensor Installation – Position Sensor

- 7.1 The inclinometer is an accelerometer-based, angular position sensor. The inclinometer needs to be installed in the vertical place.
- 7.2 To assemble the inclinometer, complete the following steps:
 - 7.2.1 Remove the position sensor from its packaging.
 - 7.2.2 Connect the sensor to the sensor cable.
 - 7.2.3 Assemble the sensor with magnets using the screws provided in the packaging.



- 7.3 The sensors must be installed perpendicular to the walking beam and above or on the saddle bearing of a conventional rod pumping unit.

Inclinometer Sensor




- 7.4 Set the brake on the pumping unit by firmly, but gradually, pulling down on the brake lever, located toward the rear of most pumping units.



- 7.5 Using fall protection, mount the sensor on the walking beam or on the saddle bearing in the orientation perpendicular to the beam. Ensure that the sensor has enough slack in the cable to move freely and unhindered once the unit is operational.





- 7.6 Use beam clamps with hook and zip tie to fasten the sensor cable along the Samson post closest to the ladder or use beam clamps with hooks to route the cable back to the VSD low voltage cabinet.




Low Voltage
Cabinet



- 7.7 Drill holes and install proper glands for load cell and position sensor cable entry into the VSD low voltage cabinet.
- 7.8 Below figure shows the position sensor terminals wiring inside the VSD low voltage cabinet.






8. Rod Pump Controller Sensor Installation – Load Cell Sensor

8.1 Each polished rod load cell possesses a label that shows the model, serial, and lot numbers, which are useful in identifying each load cell (see below for examples of a 30K, 50K).



8.2 The polished rod load cell is attached to the polished rod of an applicable pumping unit between the polished rod clamps and the carrier bar or hanger (see below Figure).



8.3 The installation of the polished rod load cell and cable assembly may require two trained personnel, a crane, and a man lift. Always wear fall protection PPE before attempting to work at heights 6' or greater


8.4 Stop the unit and apply LOTO (Lockout, Tagout) and Energy Isolation.

8.5 Set the brake on the pumping unit by firmly, but gradually, pulling down on the brake lever, located toward the rear of most pumping units.



8.6 Install the appropriately sized polished rod clamp above the stuffing box

- 8.7 Gradually release the brake and re-energize the prime mover of the pumping unit, allowing the horsehead or load belt to move and separate the carrier bar from the upper polished rod clamps.
- 8.8 Turn off the power to the pumping unit, set the brake.
- 8.9 Mark the location of the top of the existing polished rod clamp, and then remove the upper clamp and any polished rod coupling, if available.



- 8.10 Remove the pony rod, if applicable, from the top of the polished rod, as well as the polished rod coupling.



8.11 Add the alignment bearing, slide the bearing onto the polished rod, allowing it to come to rest on top of the carrier bar.




8.12 Once the alignment bearing is installed on the polished rod, the load cell should be placed on top with the “UP” directional arrow on the load cell facing up and the connector opening facing toward the pumping unit on most units.





8.13 Reinstall the upper polished rod clamps at a distance that is above the previous polished rod clamp mark, in addition to the total height of the load cell and bearing or bearings.



8.14 Remove the load cell cable assembly from its packaging and unwind the entire cable assembly. The end with the exposed wires should be left close to the VSD low voltage cabinet and the connector end can be placed toward the front end of the pumping unit. The load cell cable used will be blue in color marking intrinsic safe cable.




8.15 Disassemble the load cell connector portion of the cable assembly and apply polytetrafluoroethylene (PTFE) thread tape to the threaded connector.



8.16 Insert the threaded connector into the load cell's threaded opening and tighten by hand and/or using an appropriate wrench. Hand tighten the weather tight cap. The use of tools will over torque the cap and cause damage to the grommet.

8.17 Insert the load cell electrical connector plug into the load cell opening. Ensure the orientation of the protruding pins in the load cell's connector is correct to prevent damage to the pins.



8.18 With the load cell cable's connector firmly inserted into the load cell's connector, tighten the weather tight cap over the grommet onto the threaded connector.




8.19 Load cell cables are assembled and packaged with a thimble portion to assist with strain relief and that portion must therefore be attached to the S-hook on the load cell's arm. Use channel locks to crimp down on the S-hook once the thimble is inserted. If an S-hook is not provided, one must be added to the larger of the two holes on the load cell's arm.




8.20 Route the load cell cable around the front cross member of the Samson post

8.21 Install a zip tie or beam clamp with hook on the front cross member, and then create a loop in the cable and attach either around the zip tie or beam clamp.



8.22 Using beam clamps, along the base of the pumping unit, and then install two to three evenly spaced beam clamps with hooks up the Samson post closest to the ladder.



8.23 Moving from the top of the unit to the bottom of the unit, use the cable/zip ties to fasten load cell cable along the outline of the pumping unit.

8.24 Remove the temporary polished rod clamps using appropriate tooling




8.25 Remove energy isolation equipment and LOTO (Lockout, Tagout)

8.26 Release the brake and inspect the load cell cable to ensure that enough length is available to allow the cable to move freely and unhindered as the head of the pumping unit rises. It may be necessary to reenergize the pumping unit to allow movement of the counterweights. Extreme caution must be taken whenever the unit is energized.



8.27 Below figure shows wiring of load cell cable terminals on the VSD low voltage cabinet.




9. Powering Up the VSD

- 9.1 Remove LOTO (Lockout, Tagout) and energy isolation on the 3 phase power supply that powers the VSD.
- 9.2 Prior to energizing the VSD, open the high voltage cabinet and verify that the line voltage on the inlet phase to phase on top side of the circuit breaker does not exceed 480VAC+3%. If it does, the incoming voltage must be lowered at the utility transformer before the VSD.



- 9.3 Rotate the external breaker handle clockwise to turn on the VSD and POC, and then energize the pumping unit.




9.4 Verify the Rod Pump Controller HMI powers up and drive digital keypad comes ON.



Rod Pump Controller (RPC)
Human Machine Interface (HMI)

VSD Digital Keypad

10. Rotaflex Sensor Connection



11. Weatherford Rod Pump Controller Programming

11.1 Quick Guided Setup Menu- Is a basic menu that is primarily used when initially commissioning well. The Quick Guided Setup Menu is also useful in terms of allowing access to settings that are need regular adjustment.

11.2 QUICK GUIDED SETUP MENU STRUCTURE

10.1 Quick Guided Setup	
11.2.1 System Setup Page 1	11.2.29VSD Control
11.2.2 Press To Sync HMI Time to RTU	11.2.30SPM Min
11.2.3 Time	11.2.31SPM Max
11.2.4 Date	11.2.32SPM Start-Up
11.2.5 Idle Time	11.2.33VSD Target Fillage
11.2.6 Gauge Off Time	11.2.34Min Fillage Action
11.2.7 Pump-Up Delay	11.2.35Min Fillage
11.2.8 Power on Restart Delay	11.2.36Min Fillage Strokes
11.2.9 Sensor Setup	11.2.37Surface Tol%
11.2.10Load Input Source	11.2.38Downhole Tol%
11.2.11Preset Load Gain	11.2.39Enable
11.2.12Load Input Gain	11.2.40Rotaflex Control
11.2.13Position Input Source	11.2.41Position Min Input
11.2.14Set Top of Stroke	11.2.42Position Max Input
11.2.15Units	11.2.43Pump on Settling Time
11.2.16Surface Control	11.2.44Sensor Failure Action
11.2.17Pump-Off POS%	11.2.45# Cycles to Average
11.2.18Pump-Off Load%	11.2.46Manual Cycle Runtime
11.2.19Pump-Off Strokes	11.2.47Weatherford Rotaflex Model
11.2.20POC Method	11.2.48STA Enable
11.2.21 Pump Fillage Control	11.2.49Trim Speed Diff
11.2.22VSD Target Fillage	11.2.50Max Trans Speed
11.2.23Pump-Off Position Fillage [Min Fillage]	11.2.51 STA Segment Setup
11.2.24Pump-Off Strokes [Min Fillage Stroke]	11.2.52Well Setup
11.2.25Pump-Off Action [Min Fillage Action]	11.2.53Pump Depth
11.2.26Downhole Enable	11.2.54Bore Dia
11.2.27POC Control Source	11.2.55Fluid Depth
11.2.28Load Violation Setup	11.2.56Surface Stroke
	11.2.57Fluid Calc Method
	11.2.58Pump Efficiency
	11.2.59Rod Tapers
	11.2.60Pump Intake Pressure (PIP) Setup
	11.2.61 8500/Modbus Slave
	11.2.62Modbus Scanner
	11.2.63Save and Restart

12/01/2020 04:53:02
admin

Main Menu

View Data

Dynagraph

System Setup

Alarms

Quick Guided Setup

User Defined

Controller Diagnostic

Commands

Pump Diagnostic

Well Information

◀
Main Menu
Clear Alarms
Pump On
Idle Time
Status Screen
▶

05/15/2024 04:22:54

Quick Guided Setup

SYSTEM SETUP

Press to Sync HMI Time to RTU

HMI Time 05/15/24 - 04:22:49

RPC Time

RPC Date

Idle Time

Pump-Up Delay

Gauge Off Time (Contract Hour)

Power On Restart Delay

◀
Main Menu
Clear Alarms
Pump On
Idle Time
Status Screen
▶

05/13/2024 07:19:22

Quick Guided Setup

SENSOR SETUP

Load Input Source

Preset Load Gain

Load Input Gain lb/mV

Position Input Source

Set Top of Stroke

Units

◀
Main Menu
Clear Alarms
Pump On
Idle Time
Status Screen
▶

11.3 Load Input Source

- Load cell – Wired Load cell
- Strain Gauge
- Wireless Load cell

11.4 Preset Load Gain – Allows to choose the load cell gain. Selected load cell gain will be displayed under Load Input Gain.

Preset Load Gain

Not Selected
Not Selected
30K 1500lb/mV
50K 2500lb/mV
80K 4000lb/mV
30K-I 2143lb/mV
50K-I 3571lb/mV
80K-I 5714lb/mV


- Choose 50K-I for load cell connected to RPOC through IS barriers.

11.5 Position Input Source – Continuous/Inclinometer/Rotaflex when using inclinometer position sensor or Speed Sentry Aux position kit output on Rotaflex.

11.6 To operate VSD, position input source should be Continuous/Inclinometer/Rotaflex.

05/13/2024 07:20:15

Quick Guided Setup




SURFACE CONTROL

Pump-Off Pos %	<input type="text" value="70"/>	%	POC Method	<input type="text" value="Quadrant"/>
Pump-Off Load %	<input type="text" value="30"/>	%		
Pump-Off Strokes	<input type="text" value="2"/>			

◀ Main Menu Clear Alarms **Pump On** Idle Time Status Screen ▶

11.7 In case of Surface POC method, choose Quadrant when operating in VSD mode. Well will be controlled in Surface Quadrant pump fillage when downhole control fails.

11.8 Pump Fillage Control page is dynamic and below is the screen layout when VSD Enable flag is disabled.



11.9 Source of POC control - Downhole or Surface


0 = Surface

1 = Pump Fillage (When DH is enabled)


11.10 Downhole Method button allows user to choose the right pump fillage method.

11.11 Choose "MI:Order" method for downhole cards that show gas interference and downhole friction.

- Modified Orders Method for severe downhole friction, fluid acceleration and Rotaflex cards with load drop at bottom of stroke running in racetrack mode.
- To enable Modified orders method.
 - Choose Downhole Method to MI: Order
 - Start: Top stroke
 - End: Qtr. Point



11.12 Pump Fillage Control page changes to below layout when VSD enable flag is enabled by the drive model under VSD CONTROL page.



11.13 VSD Target fillage – Well speed controlled between Min SPM and Max SPM based on the target fillage/


11.14 Pump Off Position Fillage – When fillage drops below pump off position for the pump off strokes, well can be stopped on idle time and started back by setting pump-off action to 4 = Idle time.

11.15 Downhole Enable – Allows to enable downhole calculation based on the downhole information entered (well depth and rod string information).


11.16 POC Control Source –

- Surface Fillage – Control the well pump off from Surface Pump-Off Pos & Pump-Off Load in case of fixed speed or standard operation. Control well speed from surface fillage when VSD is enabled.

- Pump Fillage – Control the well pump off from Pump-Off Position Fillage in case of fixed speed or standard operation. Control well speed from VSD Target fillage when VSD is enabled.



- 11.17 High-High Load Limit – Well shutdowns on Off/Reset when load value goes above the limit set under High-High Load limit page.
- 11.18 Load Last Stroke, Load Since Cycle Start and Load Since Power up shows the peak load captured.
- 11.19 High Load Limit – Well keeps running with RPOC fault lamp ON when value goes above the limit set under High Load Limit page.
- 11.20 Low Load Limit - Well keeps running with RPOC fault lamp ON when value goes below the limit set under High Load Limit page.
- 11.21 Low-Low Load Limit - Well shutdowns on Off/Reset when load value goes below the limit set under High-High Load limit page.
- 11.22 Load Last Stroke, Load Since Cycle Start and Load Since Power up shows the minimum load captured.
- 11.23 Minimum Load Span – Allows to detect malfunctioning downhole pump valves.
- 11.24 Card Area – Allows to detect delayed travelling valve closure and pump issues.



ACTIONS		3			
0=Lamp Only	8=Pulse DO1	1	2	3	←
1=Soft Time	9=Pulse DO2				
2=Cntl Xfer	10=DO1 Off	4	5	6	-
3=Off/Reset	11=DO2 Off				
4=Idle Time	12=DO1 On	7	8	9	Esc
5=Idle+Alm	13=DO2 On				
6=Start Pump	x6=Pulse DOx	.	0	Enter	
7=No Action	x7=DOx Off				
	x8=DOx On				

05/13/2024 09:49:52 Weatherford

Quick Guided Setup

VSD CONTROL

SPM Min	<input type="text" value="2.00"/>	Surface Tolerance	<input type="text" value="5 %"/>
SPM Max	<input type="text" value="6.90"/>	Downhole Tolerance	<input type="text" value="5 %"/>
SPM Startup	<input type="text" value="4.30"/>	Enable	<input type="text" value="Disabled"/>
VSD Target Fillage	<input type="text" value="85 %"/>	Min Fillage	<input type="text" value="70 %"/>
Min Fillage Action	<input type="text" value="7"/>	Min Fillage Strokes	<input type="text" value="2"/>

◀
Main Menu
Clear Alarms
Pump On
Idle Time
Status Screen
▶

11.25 VSD Enable (PI250)

- 1 = WFT VSD

Enable	Disabled
	WFT VSD
	WFT F7
	WFT Regen
	WFT AC7
	Siem...G120
	ABB ACS880

Pump On
Idle Time
Status Screen



05/13/2024 09:53:14 Weatherford

Quick Guided Setup

ROTOFLEX CONTROL

Position Min Input V Sensor Failure Action

Position Max Input V # Cycles to Average

Pump On Settling Time sec Manual Cycle Runtime

Weatherford Rotaflex Model

STA Enable

Trim Speed Diff

Max Trans Speed

11.26 Rotaflex Control Page – Above page setup can be skipped for beam pumps

12/01/2020 06:18:22
admin Weatherford

Quick Guided Setup

WELL SETUP

Pump Depth ft Surface Stroke in

Bore Diam in Fluid Calc Method

Fluid Depth ft Pump Efficiency %

11.27 Fluid Stroke Calculation Method

- 0= Disabled
- 1 = Short Method (Used in surface control)
- 2 = Long Method (used in surface control)
- 3 = Downhole stroke (Should be set when downhole enabled)



05/13/2024 10:08:56
Quick Guided Setup

Rod Taper Setup

Rod Taper 1

Rod Type: Pump Depth: ft

Rod Count: Total Rod Length: ft

Rod Diameter: in

Rod Length: ft

Total Rod Tapers

Rod Taper Setup

- Rod Taper 1
- Rod Taper 1
- Rod Taper 2
- Rod Taper 3
- Rod Taper 4
- Rod Taper 5
- Rod Taper 6
- Rod Taper 7
- Rod Taper 8
- Rod Taper 9
- Rod Taper 10

Main Menu
Clear Alarms
Pump On
Idle Time
Status Screen

11.28 Total Rod Tapers screen shows the complete list of each rod tapers with count, diameter, length and total Rod Length of each taper.

05/13/2024 10:08:27
Total Rod Tapers

Page 1/4

Pump Depth: ft Total Rod Length: ft

Rod Taper	Rod Count	Rod Diameter	Rod Length	Total Rod Length
1	<input type="text" value="68"/>	<input type="text" value="1.000"/> in	<input type="text" value="25.00"/> ft	<input type="text" value="1700.00"/> ft
2	<input type="text" value="68"/>	<input type="text" value="0.875"/> in	<input type="text" value="25.00"/> ft	<input type="text" value="1700.00"/> ft
3	<input type="text" value="66"/>	<input type="text" value="0.750"/> in	<input type="text" value="25.00"/> ft	<input type="text" value="1650.00"/> ft
4	<input type="text" value="0"/>	<input type="text" value="0.000"/> in	<input type="text" value="0.00"/> ft	<input type="text" value="0.00"/> ft
5	<input type="text" value="0"/>	<input type="text" value="0.000"/> in	<input type="text" value="0.00"/> ft	<input type="text" value="0.00"/> ft

Main Menu
Clear Alarms
Pump On
Idle Time
Status Screen

11.29 Alert pop-up will show up when total rod length exceeds the pump depth. Verify each taper inputs with the well design downhole information.



05/13/2024 10:12:26

Total Rod Tapers

Page 1/4

Pump Depth ft Total Rod Length ft

Rod Taper	Rod Cou	Total Rod Length
1	<input type="text"/>	<input type="text" value="1700.00"/> ft
2	<input type="text"/>	<input type="text" value="1750.00"/> ft
3	<input type="text"/>	<input type="text" value="1650.00"/> ft
4	<input type="text"/>	<input type="text" value="0.00"/> ft
5	<input type="text"/>	<input type="text" value="0.00"/> ft

Alert

Check Rod taper input values

Total Rod length should be less than or equal pump depth

OK Rod Tapers

Main Menu Clear Alarms Pump On Idle Time Status Screen

05/13/2024 10:02:44

Quick Guided Setup

Pump Intake Pressure (PIP) Setup

Tubing Pressure

AI Selection

Override Value psi

Water Cut %

Water Specific Gravity

Oil Specific Gravity

Casing Pressure

AI Selection

Override Value psi

Bore Diameter in

Fluid Load Factor %

Calc/Buffer Type

Main Menu Clear Alarms Pump On Idle Time Status Screen

- 11.30 Tubing pressure and casing pressure transmitters analog points can be reference under AI selection.
- 11.31 Example: Tubing pressure is connected to RPOC AI1, set AI selection to AI1.
- 11.32 If the location doesn't have a transmitter and has a murphy gauge, then set the AI selection to override and under Override value enter the manual gauge value read at field site.
- 11.33 Fluid Load Factor is a manual input that represents the fluid load taken into PIP calculation considering downhole friction.



12/01/2020 17:44:49
admin

Quick Guided Setup

8500/MODBUS SLAVE

Address	<input type="text" value="1"/>	Line Mode	RS232
Data Format	8D 1S	Port	Serial
Baud Rate	19.2k	Radio ON Delay	<input type="text" value="0"/>
Protocol	8500	Radio OFF Delay	<input type="text" value="0"/>

12/01/2020 17:45:39
admin

Quick Guided Setup

MODBUS SCANNER

Stop Bits	1 Stop Bit	Line Mode	RS485
Data Format	8 Data Bit	Radio ON Delay	<input type="text" value="2"/>
Baud Rate	9600	Radio OFF Delay	<input type="text" value="2"/>
Protocol	RTU		

12/01/2020 17:50:20
admin

Quick Guided Setup

SAVE AND RESTART

System Save required after completing Quick Guided Setup.

After System Save is complete, perform RPOC Software Reset.



Communication between the RPOC and HMI will temporarily be lost during the RPOC Software Reset. Reset is complete when communication is restored.




12. Weatherford VSD Programming


12.1 Below figure shows the Weatherford A1000 & UI000 model VSD's keypad



1.1.1 Begin by accessing the programming menu, using the Up Arrow key () , followed by the ENTER key ().




1.1.2 Use the RESET key () and the Up Arrow key to first perform a two-wire initialization of the VSD.






1.1.3 Locate the motor name plate from the motor in use. Access the Auto-Tuning menu by pressing the ESC key (ESC) until the main menu displays, and then using the Up Arrow key, followed by the ENTER key. Enter the values located in **Error! Reference source not found.** in Section **Error! Reference source not found.** Additional Resources for the T parameters using the data found on the motor name plate.



12.2 It may be helpful to take a photograph of the name plate for reference (see example reference)



A1000			
AUTO TUNE AFTER VSD IS SET UP			AUTO TUNE
T1-01	1	1	TUNING MODE/W/ BELTS ON
T1-02	KW	KW	HP X 0.746=KW
T1-03	**	**	RATED VOLTAGE
T1-04	AMPS	AMPS	GET OFF OF MOTOR PLATE
T1-05	50	50	HERTZ
T1-06	**	**	# of poles = (Hz X 120)/ revolutions per minute (RPM)
T1-07	RPM	RPM	GET OFF OF MOTOR PLATE
HIT RUN FOR AUTO TUNE			

** - Enter information from Motor plate

VFD Programming Menu (settings to be changed)			
	CONVENTIONAL	ROTAFLEX	
B1-03	1	1	MOTOR STOPPING METHOD
C1-01	5	3	MOTOR ACCELERATION TIME
C1-02	5	3	MOTR DECELERATION TIME



E1-04	90	90	MOTOR MAX SPEED (Set 1.5* Motor Hertz, 1.5*60 =90Hz)
E2-02	$(f-(n*p)/120)$	$(f-(n*p)/120)$	SLIP FREQUENCY(f- base frequency, n-motor rpm, p - motor poles)
E2-03	$(\text{Motor FLA})/3$	$(\text{Motor FLA})/3$	MOTOR NO LOAD CURRENT
H1-05	4	4	AUTO SWITCH INPUT
H2-01	E	E	DIGITAL OUTPUT M1-M2 FUNCTION
H2-02	E	E	DIGITAL OUTPUT M3-M4 FUNCTION
H2-03	NA	37	M5-M6 /ROTAFLEX - POWER CYCLE SPEED SENTRY AUX POS PLC KIT (ONLY ON OLD AUX POSITION KIT model - 6ES7 212-1BB23-0XB0)
H3-03	100	100	HAND MODE SPEED GAIN (ANALOG 1)
H3-10	3	3	RPOC SPEED REFERENCE (ANALOG 2)
H4-01	109	109	FM ANALOG OUT
H5-01	7	7	RTU ADDRESS
H5-06	15	15	TRANSMIT WAIT TIME
H5-11	1	1	COMMUNICATION ENTER FUNCTION
L2-01	1	1	POWER LOSS RIDETHROUGH
L2-02	2.1	2.1	RIDETHROUGH TIME
L5-01	5	0	NO OF STARTS
L7-01	100	100	MAX FWD TORQUE (CLOCK WISE CRANK ROTATION)
L7-02	100	100	MAX REV TORQUE (COUNTER - CLOCK WISE CRANK ROTATION)
L7-03	15	100	Max Braking (CLOCK WISE CRANK ROTATION)
L7-04	15	100	Max Braking (COUNTER - CLOCK WISE CRANK ROTATION)
L8-55	0	0	INTERNAL BRAKING TRANSISTOR
O1-10	900	900	U1-01 DISPLAY (900 IF E1-04 =90Hz)
O1-11	1	1	U1-01 DISPLAY UNIT DECIMAL DISPLAY
P1-07	5	0	SPEED/TORQUE RESTARTS
P3-01	1	1	Wait between restarts
P3-03	1	1	A1 SPEED REF
HARMONIC FILTER ON FRONT END			
	Pump Jack	Rotaflex	
L4-01	8	8	Speed detection level to close DO to bring the harmonic caps in circuit
L4-02	5	5	DO will open when speed (L4-01) minus (L4-02) is detected
H2-03	5	5	DO closes when speed set in L4-01 is detected

Program the correct DO wired into Harmoic Filter when used with Rotaflex



U1000 Programming

A1-03	2220	INITIALIZES VFD
AUTO TUNE AFTER VFD IS CONNECTED TO MOTOR		
AUTO TUNE MENU - PARAMETERS		
T1-01	4	TUNING MODE with BELTS ON
T1-02	KW	HP X 0.746=KW
T1-03	460(U.S.)	Motor RATED VOLTAGE
T1-04	AMPS	GET OFF OF MOTOR PLATE
T1-05	60(U.S.)	Motor HERTZ
T1-06	6	# of poles = (Hz X 120)/RPM
T1-07	RPM	GET OFF OF MOTOR PLATE
T1-09	No - load current	(Motor FLA)/3
T1-10	Motor Rated Slip	(f-(n*p)/120). Where f- base frequency, n-motor rpm, p - motor poles
HIT RUN FOR AUTO TUNE		

VFD Programming Menu (settings to be changed)

	CONVENTIONA L	ROTAFLEX	
B1-03	1	1	MOTOR STOPPING METHOD
C1-01	5	3	MOTOR ACCELERATION TIME
C1-02	5	3	MOTR DECELERATION TIME
C7-60	1	1	Output Voltage Limit Selection. 1 = High Voltage mode
E1-04	90	90	MOTOR MAX SPEED (Set 1.5* Motor Hertz, 1.5*60 =90Hz)
E2-02	(f-(n*p)/120)	(f-(n*p)/120)	SLIP FREQUENCY(f- base frequency, n-motor rpm, p - motor poles)
E2-03	(Motor FLA)/3	(Motor FLA)/3	MOTOR NO LOAD CURRENT
H1-06	F	F	Not Used
H1-05	4	4	AUTO SWITCH INPUT
H1-08	25	25	TVSS FAULT INPUT (Normally closed)
H2-01	E	E	DIGITAL OUTPUT M1-M2 FUNCTION
H2-02	E	E	DIGITAL OUTPUT M3-M4 FUNCTION
H2-03	NA	37	M5-M6 /ROTAFLEX - POWER CYCLE SPEED SENTRY AUX POS PLC KIT (ONLY ON OLD AUX POSITION KIT model - 6ES7 212-1BB23-0XB0)
H3-03	100	100	HAND MODE SPEED GAIN (ANALOG 1)
H3-10	3	3	RPOC SPEED REFERENCE (ANALOG 2)



H4-01	109	109	FM ANALOG OUT
H5-11	1	1	COMMUNICATION ENTER FUNCTION
L2-01	1	1	POWER LOSS RIDETHROUGH
L2-02	2.1	2.1	RIDETHROUGH TIME
L2-03	4	4	MOMENTORY POWER LOSS MINIMUM BASEBLOCK TIME
L3-04	1	0	STALL PREVENTION
L5-01	5	0	NO OF STARTS
L7-01	100	100	MAX FWD TORQUE (CLOCK WISE CRANK ROTATION)
L7-02	100	100	MAX REV TORQUE (COUNTER - CLOCK WISE CRANK ROTATION)
L7-03	15	100	Max Braking (CLOCK WISE CRANK ROTATION)
L7-04	15	100	Max Braking (COUNTER - CLOCK WISE CRANK ROTATION)
N2-01	1	1	AFR GAIN
O1-10	900	900	U1-01 DISPLAY (900 IF E1-04 =90Hz)
O1-11	1	1	U1-01 DISPLAY UNIT DECIMAL DISPLAY
P3-01	1	1	Wait between restarts
VFD Programming Default Settings			
	CONVENTIONAL	ROTAFLEX	
A1-02	2	2	CONTROL METHOD
B5-01	0	0	PID MODE
B5-19	0	0	PID LOOP SETPOINT
C6-01	1	1	DRIVE OUTPUT SELECTION: HEAVY/NORMAL DUTY
H1-06	85	85	HAND CONTROL INPUT
H3-02	24	24	HAND SPEED REF (ANALOG 1)
H3-11	100	100	A2 MAX SPEED
H3-12	0	0	A2 MIN. SPEED
H4-07	0	0	FM SIGNAL
O1-03	3	3	DRIVE KEYPAD DISPLAY U1-01 (Hz)
O2-01	1	1	LOCAL/REMOTE KEY SELECTION
O2-06	0	0	DIGITAL OP DISCONNECT STATE
P1-08	2	2	LOW SPEED RESTART TIME